

Configuring the OMS to power up after power loss

A USB keyboard and monitor (VGA or HDMI, check the back of the server) are required to complete these steps.

Power off the server.


Plug in your keyboard and monitor.

Power up the server and immediately hit the key. This will load the BIOS.


Use the RIGHT ARROW key to bring yourself to the POWER menu.




Press the Enter key to bring up the selection menu and change the state to "Power On"




The setting should now look like this:



Press F10 and choose "Exit Saving Changes"



Press "Y" when prompted



The system will then restart.